

ARTESIAN SERIES BASIN | INSTALLATION INSTRUCTIONS

All basin installations need to be carried out by a licenced installer. Installers must inspect the product prior to installation to ensure it is free from damage.

1.
Ensure both the benchtop and the underside of the basin are clean and free of debris.

2.
Apply a circle of clear flexible bathroom silicone to the underside of the basin, centred between the perimeter of the basin and the waste hole.

3.
Align the basin wastehole to the bench wastehole and then press the basin down onto the benchtop.

4.
Ensure that the waste is installed with rubbers on both the top and bottom, and be sure to not over-tighten.

*****PLEASE NOTE*****

All concrete basins must be installed with a flexible-type sealant. The use of non-flexible sealant, liquid nails, or epoxy of any kind can damage the product and will void the warranty.